X0[®] 4 / X0[®] FLEX UPGRADE OF SUCTION HOSE SYSTEM MK2

YB-802 Version 1.01

XO CARE A/S Usserød Mølle Håndværkersvinget 6 DK 2970 Hørsholm Denmark

+45 70 20 55 11 info@xo-care.com www.xo-care.com



Needed tools:

- 1. TORX 10 screwdriver
- 2. TORX 20 screwdriver
- 3. Slot-type screwdriver ≤ 2.5 mm

Kit, part no.:

 KT-062: Kit, Upgrade to Suction Hose System Auto Return MK2

WARNING:

When making changes and handling electronics in the XO 4 Unit – always use ESD antistatic wristband (UC-600)



Switch the unit off

Remove the plastic part by removing the 4 screws illustrated.



Disconnect the old PCB, unscrew the two M3 screws and remove the PCB.



Fit the new PCB (AD-633 / AO-989) with the same two screws and re-connect.



Switch the unit on


To ensure that the sensitivity of the PCB is optimal, please adjust R50 until diode D1 and D2 are equally bright. Perform the same adjustment on R51 for diode D4 and D5.



When the four LEDs are equally bright, switch the unit off.



Refit the plastic part while taking care of not bending the sensor components.



Check the function using the MK2 hoses.

