

XO[®] 4

RETROFIT OF XO ODONTOCURE

YB-030
Version 1.00

XO CARE A/S
Usserød Mølle
Håndværkersvinget 6
DK 2970 Hørsholm
Denmark

+45 70 20 55 11
info@xo-care.com
www.xo-care.com



WARNING:

When making changes and handling electronics in the XO 4 Unit – always use ESD antistatic wristband (UC-600).



Tools:
Torx 20
Torx 10



The complete kit.
XO-076 XO Odontocure



Remove the end caps from the instrument bridge.




Loosen the two torx-20 bolts in the instrument bridge top cover. Remove the top cover.




Loosen the right-hand attachment bolts for the suspension rack.




Loosen the left-hand attachment bolt for the suspension rack.




Loosen the three attachment bolts on the suspension rack.




Make sure to remove the correct bolts.




Remove the suspension rack




Loosen the three PCB rack attachment bolts.




Loosen the three PCB rack attachment bolts.




Disconnect all air, water and electric connections, and remove the PCB rack.




Remove the 3 upper attachment bolts in the right-hand side of the valve block rack.



Remove the lower attachment bolt from the valve block rack.




Disconnect cable CA-101.




Remove the valve block from the position where you want to install the XO Odontocure, and install the supplied block.




IMPORTANT:
If the new block is installed in the last position, make sure that the endcap is mounted on the last water-bearing suspension to prevent stagnant water.



Re-assemble the block rack with the new block.



Re-assemble the complete PCB rack in the bridge, and connect all cables and hoses.



In the technician menu select:
"SUSP #" = "LC LAMP"
"SPCB #" = "AD-605"

Update firmware to latest version or
adjust curing time to 5, 10 and 20 s.

Check that all suspensions are working
properly.